



LogTag Online Bulk Shipments

© Copyright LogTag International, 2024

Revision 0.1

Wednesday, August 21, 2024

Contents

Bulk Shipments	3
Creating a Shipment Profile	3
Name the Shipment Profile	4
Add the Primary Coordinator	4
Select Notifications	5
Choose the default shipment areas	5
Creating a new shipment area	5
Define the alarm profile	6
Select the Estimated Journey Duration	6
Save the Shipment Profile	7
Using Bulk Shipments	8
Creating a list of loggers	8
Naming the bulk shipments	9
Paste the details	10

Revision	Date	Author	Comment
0.1	21 August 2024	AJB	Initial

Bulk Shipments

If many shipments are to be created it is more convenient to use the “Bulk Shipments” option instead of creating each shipment individually. With many loggers this will significantly save time when entering data into LogTag Online as a cut and paste approach can be used.

The following steps need to be taken to successfully use bulk shipments, in the examples given it is assumed the LT5GEO will be used:


1. **“Create a LogTag Online Account”**: Covered in the LogTag Online System Guide
2. **“Creating a Shipment Profile”**: Show how to create a shipment profile which will be used as the default for any shipment created
3. **“Using Bulk Shipments”**: Use this method to easily create shipments based on the loggers that will be used
4. **“Start the Logger”**: Covered in the LogTag Online System Guide
5. **“Complete the Shipment”**: Covered in the LogTag Online System Guide

Creating a Shipment Profile


A shipment profile allows a default set of options to be configured which can be used over and over again. A profile covers configurable items from shipment origin and destination as well as temperature profiles, cellular transmission intervals and any notifications that are to be sent.

If only one shipment profile has been created this will always be used. If multiple shipment profiles have been created then these can be selected.

To create a shipment profile choose “Shipment Profiles” on the “Shipment” screen



Select “Create New” to create a new shipment profile



Name the Shipment Profile

Enter the name for the shipment profile. Keep in mind the origin and destination as well as thinking of the temperature profile that will be used.

Shipment Profiles

Additional Info

?

Manage Shipment Profiles

Create new

Shipment Profile Name

Shipment Profile Name is required.

In this example “LogTag->World Health (Ambient)” was used indicating that this is the default profile that should be used if the shipment is going to be sent from LogTag to Word Health with an ambient temperature profile.

Add the Primary Coordinator

Choose who the Primary Coordinator for this shipment profile is. They will receive any notifications for shipments using this profile. Select Secondary and Emergency if necessary.

Shipment Profiles

Additional Info

?

Manage Shipment Profiles

Create new

LogTag->World Health (Ambient)

SHIPMENT PROFILE SETTINGS

ALARM DETECTED

Notify Via:

☒ Email

☒ SMS

Who Should Be Notified:

☒ Primary Coordinator

☐ Secondary Coordinator

☐ Emergency Contacts

☐ Use the same settings for humidity sensor events (if supported)

SHIPMENT COMPLETED

Notify Via:

☒ Email

☒ SMS

Who Should Be Notified:

☒ Primary Coordinator

☐ Secondary Coordinator

☐ Emergency Contacts

POWER & LIGHT NOTIFICATIONS

Notify Via:

☒ Email

☒ SMS

Who Should Be Notified:

☒ Primary Coordinator

☐ Secondary Coordinator

☐ Emergency Contacts

☐ Use the same settings for light sensor events (if supported)

TEAM DETAILS

PRIMARY COORDINATOR

Aaron Blanchard

Please select

Aaron Blanchard

Chris Turner

LogTag Online

EMERGENCY COORDINATOR

Please select

Select Notifications

Decide who should receive notifications based on the tick boxes presented.

Choose the default shipment areas

Shipment areas allow visibility of where the shipment is going from and to. Email, SMS, Whatsapp or voice notifications can be sent when the shipment has arrived in the circle governed by the default destination. Select “Create new” for a new shipment area.

DESTINATION BOUNDARY ARRIVAL

Notify Via:

☒ Email

☒ SMS

Who Should Be Notified:

☒ Primary Coordinator

☐ Secondary Coordinator

☐ Emergency Contacts

SHOCK NOTIFICATIONS

Notify Via:

☒ Email

☒ SMS

Who Should Be Notified:

☒ Primary Coordinator

☐ Secondary Coordinator

☐ Emergency Contacts

DEFAULT SHIPMENT AREAS

Origin:

Select

|

Create new

Team LogTag

customer 1

warehouse

Creating a new shipment area

Choose a distinct name and search for the address and choose “Create” to save it.

CREATE AREA

NAME

Word Health

ADDRESS

Search for an address

World Health Organization - M Building, Av. Appia 20, Genève, Geneva 1202, Switzerland

km | 2.2

BOUNDARY SIZE (RADIUS)

MARK AREA BOUNDARY

CANCEL Create

Define the alarm profile

Clicking on the question mark will show the details of the profile that has been selected.

Who Should Be Notified:

- ☒ Primary Coordinator
- ☐ Secondary Coordinator
- ☐ Emergency Contacts

Destination: Select LogTag International

Custom

No alarms have been set

Recording Interval: 10 minutes

28 Days

For this example choosing the “Generic Ambient” profile is desired:

Who Should Be Notified:

- ☒ Primary Coordinator
- ☐ Secondary Coordinator
- ☐ Emergency Contacts

Destination: Select LogTag International

Generic Ambient (Unsaved)

Temperature Alarms

25 °C Upper
Trigger after 2 consecutive violations (20 minutes)

15 °C Lower
Trigger after 2 consecutive violations (20 minutes)

Recording Interval: 10 minutes
Alarm (Red) Indicator: ON
Allow logging stop with "START/CHECK" button: OFF

Select the Estimated Journey Duration

The estimated journey duration directly affects how frequently the LT5GEO will connect to the cellular network to send data and determine its location. This can vary from every hour to every day depending on the length of the journey. See the LogTag Online LT5GEO System guide for the current range of values (Note: This interval may change to be more frequent)

ESTIMATED JOURNEY

3 Days

Save the Shipment Profile

Under team details select Save.

TEAM DETAILS

PRIMARY COORDINATOR

Aaron Blanchard



SECONDARY COORDINATOR

Please select



EMERGENCY COORDINATOR

Please select




SAVE

This shipment profile is ready to use.


Using Bulk Shipments

Creating a list of loggers

Logger serial numbers for bulk shipments can be prepared beforehand in a text editor or a spreadsheet etc., the only requirement is that before pasting this information into LogTag Online that a space is placed between each shipment as in the example below:




Multiple loggers can be added to a shipment by adjusting where the spaces are:




Naming the bulk shipments

If no shipment name is given, then one will be allocated to the shipment. This can be changed later if required.


With the examples give so far, the shipments would appear as:



If a specific name is required, then this can be added into the text document (Having the serial number in the shipment name may be useful depending on the use case):



Which would appear as:



Paste the details

Paste in the details and choose “Create” - the shipments will be created and put into a “Pending” state. After the LT5GEO is started and first connects, this state will transition from “Pending” to “In Transit”.

Bulk Shipment Creator



Create multiple shipments with multiple loggers per shipment by pasting serial numbers in the area below

LogTag->Word Health (Ambient)
A0D8001001I5

LogTag->Word Health (Ambient)
A0D8001002SH

LogTag->Word Health (Ambient)
A0D80010032O

Add Logger serials 1 per line. When you wish to create a new shipment, simply leave a blank line between serial numbers. Only 5 serial numbers may be added per shipment.

You can also add Shipment Names by writing your desired Shipment name on the first line after a space declaring a new Shipment.



Cancel

Create & Start

Create